1G10FO

Multifunctional LED Flashlight



EDC BY KBS

OPERATING INSTRUCTIONS

Thank you for purchasing the Bright Star 1G10FO Multifunctional LED Flashlight!

Read all warnings and instructions thoroughly before first use

Unscrew tail cap and remove battery insulator before first use

Operating Instructions

Proper care of your new light is essential to get a long dependable life of service. Please take some time to review this instruction sheet before using your new flashlight.

The flashlight comes with a rechargeable Li-Ion battery. The Li-Ion battery provides up to 5 hours of continuous runtime with a 4-hour charge.

CHARGING INSTRUCTIONS:


The rechargeable battery inside the 1G10FO Multifunctional LED Flashlight is designed to be charged inside the flashlight. Removing the Li-Ion battery from the light is not necessary. Simply insert a USB-C cable into the designated charge port.



Once the flashlight is plugged in, the charging indicator to the right of the charging port will turn RED, indicating the unit is charging. In order to get the longest runtime out of your 1G10FO LED Flashlight, leave the flashlight on the charger until the charging indicator turns green.

MODE SWITCH INSTRUCTIONS:

A push-button switch on the rear end of the flashlight, shown in Figure 2, turns the light on and off. A metal tactical switch next to the main switch cycles the light through various light modes (High – Med – Low – Strobe). The light will default to high mode when turned on, and the first tactical switch press will turn the light on in medium mode, the 2nd switch press will switch the light to low mode, the 3rd switch press will switch the light to strobe mode, and the 4th switch press will return the light back to high mode.



Regular Switch
1st Press: ON
2nd Press: OFF
Tactical Switch
Default: HIGH
1st Press: MED
2nd Press: LOW
3rd Press: HIGH

STROBE MODE:
Hold Tactical Switch

Safety:

- Flashlight will generate heat while working.
- Do not clean the flashlight with harsh chemicals, use only mild detergent and water.
- Do not dispose of the Li-Ion battery pack in fire, the battery may cause serious injuries
- Please refer to local ordinances regarding Li-Ion battery disposal
- Use of this product for any other purpose than a flashlight is prohibited.

Warranty: This product is subject to a 1-year warranty from date of purchase for any manufacturing defects. Proof of purchase may be required.

See more at
www.FLASHLIGHT.com

KoehlerBrightStar™

Koehler-Bright Star LLC 380 Stewart Road Hanover Township, PA USA 18706-1459 Phone: 570-825-1900 Toll Free: 1-800-788-1696

1G10FO

Multifunctional LED Flashlight



EDC BY KBS

OPERATING INSTRUCTIONS

Thank you for purchasing the Bright Star 1G10FO Multifunctional LED Flashlight!

Read all warnings and instructions thoroughly before first use

Unscrew tail cap and remove battery insulator before first use

Operating Instructions

Proper care of your new light is essential to get a long dependable life of service. Please take some time to review this instruction sheet before using your new flashlight.

The flashlight comes with a rechargeable Li-Ion battery. The Li-Ion battery provides up to 5 hours of continuous runtime with a 4-hour charge.

CHARGING INSTRUCTIONS:


The rechargeable battery inside the 1G10FO Multifunctional LED Flashlight is designed to be charged inside the flashlight. Removing the Li-Ion battery from the light is not necessary. Simply insert a USB-C cable into the designated charge port.



Once the flashlight is plugged in, the charging indicator to the right of the charging port will turn RED, indicating the unit is charging. In order to get the longest runtime out of your 1G10FO LED Flashlight, leave the flashlight on the charger until the charging indicator turns green.

MODE SWITCH INSTRUCTIONS:

A push-button switch on the rear end of the flashlight, shown in Figure 2, turns the light on and off. A metal tactical switch next to the main switch cycles the light through various light modes (High – Med – Low – Strobe). The light will default to high mode when turned on, and the first tactical switch press will turn the light on in medium mode, the 2nd switch press will switch the light to low mode, the 3rd switch press will switch the light to strobe mode, and the 4th switch press will return the light back to high mode.



Regular Switch
1st Press: ON
2nd Press: OFF
Tactical Switch
Default: HIGH
1st Press: MED
2nd Press: LOW
3rd Press: HIGH

STROBE MODE:
Hold Tactical Switch

Safety:

- Flashlight will generate heat while working.
- Do not clean the flashlight with harsh chemicals, use only mild detergent and water.
- Do not dispose of the Li-Ion battery pack in fire, the battery may cause serious injuries
- Please refer to local ordinances regarding Li-Ion battery disposal
- Use of this product for any other purpose than a flashlight is prohibited.

Warranty: This product is subject to a 1-year warranty from date of purchase for any manufacturing defects. Proof of purchase may be required.

See more at
www.FLASHLIGHT.com

KoehlerBrightStar™

Koehler-Bright Star LLC 380 Stewart Road Hanover Township, PA USA 18706-1459 Phone: 570-825-1900 Toll Free: 1-800-788-1696